


CONFY CARE®



CFMC03A
Portable Massage Table
INSTALLATION MANUAL

Before you start using your new chair, please read this operation manual thoroughly (especially the section on Safety) for the correct usage and operation .
Be sure to keep this manual available for future reference. It is your guide to safe,efficient operation.

Table of Contents

Safety	Page 1
Names of parts and functions	Page 1
Setting up your chair	Page 2
Product care and storage	Page 4
Benifits of massage	Page 5


▲ Take the material object as the standard

Safety

▲ Do not exceed the maximum weight limit of 500lbs/22kgs.

Do no use abrasive cleaning agents like benzene or thinner to clean the chair.
Always ensure that both leg stabilisers (front and back) are on the same level and tighten strap to prevent the chair from collapsing.

Names of Parts and Functions



1. Headrest Pad

2. Chest Pad

3. Seat Pad

4. Leg Stabilizers

5. Headrest Pad Frame

6. Armrest Pad

7. Main Frame

8. Chair Strap

9. Knee Pad


10. Seat Frame

11. Castors


12. Chest Frame

Setting up Your Chair


1. Unpack the chair and place all the parts on the floor.




2. Position the chair at standing position




3 Insert headrest pad frame into chest frame



4. Attach chest pad onto chest frame




5. Attach seat pad onto seat frame



Setting up Your Chair


6. To adjust the height of headrest pad:

- Press and hold the locking clips.
- Adjust headrest pad to the desired height.
- Release the locking clips.




7. To attach headrest pad:

- Release the two locking handles.
- Align and fix the Velcro on the headrest pad onto the headrest pad frame.
- Secure the two locking handles.




8. To adjust the angle of headrest pad:

- Release the two locking handles.
- Adjust headrest pad to desired angle.
- Secure the two locking handles.




9. To adjust the height of armrest:

- Raise armrest by pulling the nylon belt.
- Lower armrest by pushing buckle downwards to release the nylon belt.



10. To adjust the angle of armrest pad:

- Release the two locking handles.
- Adjust armrest pad to desired angle, then secure the two locking handles.




▲ Do not exert excessive force on the Armrest.

Setting up Your Chair

11. To adjust inclination of chair:


Major Adjustment

- Place the chair on the floor as shown below.
- Unscrew the pin from the adjuster.
- Slide the adjuster to the desired position.
- Insert the pin into the adjuster.
- Secure the plastic knob.



Minor Adjustment


- Place the chair in standing position.
- Push the main frame forward.
- Turn the adjuster to desired position to make minor inclination :



Product Care and Storage

1. To fold chair:

- Remove chest pad and turn seat assembly upward before collapsing chair.



2. To move chair:

- Pull chair by its front castors to desired location.



3. To maintain chair:

- Inspect closely all structural components of your chair.
- Be sure that all connections are tight and the frame, legs and braces are free of cracks.

4. To store chair:

- Do store your chair in a cool and dry place.

5. To clean chair:

- It is important that oil is prevented from contacting the fabric or is promptly cleaned if exposed.

Benefits of Massage


Massage may help to:

- Relieve chronic muscular tension.
- Improve joint flexibility.
- Enhance blood circulation.
- Reduce mental and physical fatigue.
- Promote faster healing of injured muscular tissue.
- Promote better sleep.
- Create an overall sense of well-being.


Rolling Massage



Kneading Massage



Pushing Massage



Tapping Massage

